

# **Anterior**Chairside Preparation Guide

#### For IPS e.max® Restorations


		IPS e.max Ceram/ZirPress	IPS e.max ZirCAD	IPS e.max CAD/Press
Anterior	Crown		Х	Χ
	Veneer	Х		
	Bridge		Х	X
Posterior	Crown		Х	Х
	Bridge		Х	

all ceramicall you need




### **Full-Coverage Restorations**

#### **ANTERIOR CROWN PREPARATION**



### **3-Unit Bridge Restorations**

#### 3-UNIT BRIDGE PREPARATION



### **Veneers**


#### **VENEER PREPARATION**

A medium grit, round-ended, diamond bur is used to remove a uniform thickness of facial enamel by joining the depth-cut grooves.




#### **INCISAL PREPARATION**

The diamond bur is angled to bevel back the incisal edge.



#### **CHAMFER MARGINS**

Correct preparation of the chamfer margins interproximally allows the appropriate bulk of porcelain.





\*Please note: For additional masking capabilities and/or layering techniques, further reduction may be necessary.

Contact your laboratory for further information.

### **3-Unit Bridge Restorations**


#### 3-UNIT BRIDGE PREPARATION






### **Full-Coverage Restorations**

#### POSTERIOR CROWN PREPARATION



## CONVENTIONAL CEMENTATION PREPARATION



When layered or pressed ceramic margins are preferred in conjuction with a zirconia framework, enhanced gingival esthetics can be achieved with a definitive 90 degree shoulder prreparation.



